




WELD THE WORLD

MicroMag 225

Instruction Manual

ENGLISH

Translation of the original instructions





ENGLISH

GENERAL CONTENTS

GENERAL INFORMATION.....	6
INSTALLATION AND ASSEMBLY.....	7
CONNECTIONS AND SOCKETS.....	7
PREPARING FOR MIG/MAG WELDING	8
PREPARING FOR MMA WELDING	11
PREPARING FOR TIG WELDING.....	13
USER INTERFACE	15
Display	17
PRELIMINARY SETTINGS.....	18
LANGUAGE SETTING	18
FIRMWARE UPDATE.....	19
If problems are found in the update, the display shows a notice.	20
SYSTEM SETTINGS	21
Wire feed setting	22
Cooling unit setup	23
LOCK (Locking/Unlocking changes)	24
MOTOR GENERATOR	27
MIG/MAG WELDING.....	28
WELDING CIRCUIT CALIBRATION	28
GAS FLOW ADJUSTMENT	30
WELDING PROGRAM SETTING	31
MIG/MAG Welding processes	33
MIG/MAG welding functions.....	34
MIG/MAG TORCH TRIGGER MODE SETTING	35
Process parameters with torch trigger in 2-strokes and 4-strokes mode	37
Process parameters with torch trigger in 2-strokes and 3 levels mode.....	38
Process parameters with torch trigger in 4-strokes and 3 levels mode.....	40
MIG/MAG 2T OPERATION	42
MIG/MAG 2T SPOT OPERATION	43
MIG/MAG 4T OPERATION	44
MIG/MAG 4T B-LEVEL OPERATION.....	45
MIG/MAG 2T - 3 LEVELS OPERATION	46
MIG/MAG 2T SPOT - 3 LEVELS OPERATION.....	47
MIG/MAG 4T - 3 LEVELS OPERATION	48
MIG/MAG 4T B-LEVEL - 3 LEVELS OPERATION.....	49
PARAMETERS SETTING.....	50
PROCESS PARAMETERS SETTING	51
SETTING DOUBLE PULSE PARAMETERS	52
Double pulse parameters	53
JOB SELECTION SETTING.....	54
B-LEVEL SETTING	56
SPOT/PAUSE FUNCTION SETTING.....	58

ENGLISH

MMA WELDING	60
MMA PROCESS SETUP	60
PROCESS PARAMETERS SETTING	61
MMA PARAMETERS (PARAMETERS MENU)	62
TIG LIFT WELDING	63
TIG LIFT PROCESS SETTING	63
TIG TORCH TRIGGER MODE SETTING	64
Process parameters with torch trigger in 2-strokes and 4-strokes mode	66
TIG LIFT 2T OPERATION	67
TIG LIFT 4T OPERATION	68
JOBS MANAGEMENT	69
SAVING A JOB	69
Keyboard functions	70
OVERWRITE A JOB	71
LOAD A JOB	72
DELETING A JOB	72
EXPORT JOBS	73
IMPORT JOBS	74
FAST JOB	75
RESET	76
Reset Mode	76
RESET PARAMETERS	76
RESET PARAMETERS AND JOBS	78
FACTORY RESET	80
ALARM MANAGEMENT	82
INFO SYSTEM	86
SERVICE	87
TECHNICAL DATA	89
MicroMag 225	89
SPARE PARTS	91
WIRE FEEDER ROLLS	91



ENGLISH

1 GENERAL INFORMATION



IMPORTANT! For your safety

This handbook must be consigned to the user prior to installation and commissioning of the unit.

Read the manual "GENERAL INSTRUCTIONS FOR USE" provided separately from this manual before installation and commissioning of the equipment.

The meaning of the symbols in this manual and the associated precautionary information are given in the "GENERAL INSTRUCTIONS FOR USE".

If the "GENERAL INSTRUCTIONS FOR USE" are not present, it is mandatory to request a replacement copy from the manufacturer or from your dealer.

Retain these documents for future consultation.

Meaning of the symbols



DANGER!

This pictogram warns of danger of death or serious injury.



WARNING!

This pictogram warns of a risk of injury or damage to property.



CAUTION!

This pictogram warns of a potentially hazardous situation.



WARNING!

This pictogram gives important information concerning the execution of the relevant operations.



Information

This pictogram indicates additional information or refers to another section of the manual with the related information.

○ in the tables:

- minimum value
- default value
- maximum value


○ in the illustrations:

- press
- turn the encoder
- press the encoder

- **Note:** The figures in this manual are purely guideline and the images may contain differences with respect to the actual equipment to which they refer.

2 INSTALLATION AND ASSEMBLY

2.1 CONNECTIONS AND SOCKETS



- [1] Polarity selector cable.
- [2] Negative polarity welding socket.
- [3] Positive polarity welding socket.
- [4] EURO TORCH welding socket.
- [5] Network protection LED activation.
This LED lights up in the event of a missing phase in the power line of the equipment.
- [6] Switch for switching the generator off and on.
- [7] Connector for the gas supply hose between the cylinder and the generator.
- [8] Connector for powering the cooling unit.
 - Voltage: 400 Va.c.
 - Current Dispensed: 0.8 A
 - IP protection class: IP20 (cap open) / IP66 (cap closed)
- [9] Power cable.
 - Length: 2.4 m
 - Number and section of conductors: 3 x 2.5 mm²
 - Type of electrical plug: Schuko

ENGLISH

2.2 PREPARING FOR MIG/MAG WELDING



DANGER!


Lifting and positioning

Read the warnings highlighted by the following symbols in the “General instructions for use”.



WARNING!

For the cooler to power source assembly procedure refer to the cooler instruction manual.




1. Set the welding power source ON/OFF switch to “O” (unit switched off).
2. Connect the gas hose from the welding gas cylinder to the rear gas socket.
3. Open the cylinder gas valve.
4. Connect the MIG/MAG torch plug to the EURO TORCH welding socket.
5. Connect the plug of the ground clamp to the negative polarity welding socket.
6. Connect the plug of the polarity selector cable to the positive polarity welding socket.
7. Connect the earth clamp to the workpiece being processed.
8. Place the coil of wire in the spool and insert the wire into the wire feeder.


Positioning the wire spool and the wire in the wire feeder

**WARNING!****Mechanical risks**



Read the warnings highlighted by the following symbols in the "General instructions for use".



9. Open the unit side door to gain access to the spool compartment.




10. Unscrew the cap of the spool holder.




11. Fit the spool in the spool holder, ensuring it is located correctly.


12. Calibrate the coil holder spool braking system by tightening/loosening the screw.




13. Refit the plug.



14. Lower the wire feeder pressure devices.



15. Raise the wire feeder pressure arms.




16. Feed the wire between the wire feeder rolls and insert it into the MIG/MAG TORCH connector plug.

ENGLISH


17. Check that the feed rolls are suitable for the wire gauge.

i Information follow the instructions on page [91](#).


18. Make sure the wire is located correctly in the roll grooves.



19. Close the wire feeder pressure arms.



20. Adjust the pressure system so that the arms press the wire with a force that does not deform it while also ensuring constant feed rate without slipping.



21. Close the unit side door.

22. Connect the power source mains supply cable to the mains socket outlet.



DANGER!

Electric shock hazard!

Read the warnings highlighted by the following symbols in the "General instructions for use".



23. Set the welding power source ON/OFF switch to "I" (unit powered).


2.3 PREPARING FOR MMA WELDING

**DANGER!****Lifting and positioning**


Read the warnings highlighted by the following symbols in the “General instructions for use”.



FRONT VIEW



REAR VIEW



1. Set the welding power source ON/OFF switch to “O” (unit switched off).
2. Choose the electrode based on the type of material and thickness of the workpiece to be welded.
3. Insert the electrode in the electrode holder.
4. Connect the electrode holder cable to the welding socket based on the polarity requested by the type of electrode used.
5. Connect the plug of the ground clamp to the welding socket on the basis of the polarity required.
6. Connect the earth clamp to the workpiece being processed.
7. Plug the power cable plug into a mains socket outlet.

ENGLISH



DANGER!

Electric shock hazard!

Read the warnings highlighted by the following symbols in the “General instructions for use”.



8. Set the welding power source ON/OFF switch to “I” (unit powered).


2.4 PREPARING FOR TIG WELDING

**DANGER!****Lifting and positioning**

Read the warnings highlighted by the following symbols in the "General instructions for use".

**WARNING!**

For the cooler to power source assembly procedure refer to the cooler instruction manual.



1. Set the welding power source ON/OFF switch to "O" (unit switched off).
2. Connect the gas hose from the welding gas cylinder to the rear gas socket.
3. Open the cylinder gas valve.
4. Connect the TIG torch plug to the EURO TORCH welding socket.
5. Choose the electrode based on the type of material and thickness of the workpiece to be welded.
6. Insert the electrode in the TIG torch.
7. Connect the torch plug to the welding socket on the basis of the polarity required by the type of electrode in question.
8. Connect the plug of the ground clamp to the welding socket on the basis of the polarity required.
9. Connect the earth clamp to the workpiece being processed.
10. Plug the power cable plug into a mains socket outlet.

ENGLISH



DANGER!

Electric shock hazard!


Read the warnings highlighted by the following symbols in the “General instructions for use”.







11. Set the welding power source ON/OFF switch to “I” (unit powered).












3 USER INTERFACE

MicroMag 225




ELEMENT	FUNCTION
	Port provided to connect a USB pen drive to export/import JOBs. The system firmware can be updated via the USB port.
 <div><div>2</div><div>a</div><div>b</div><div>c</div><div>d</div><div>e</div><div>f</div></div>	The lighting of the LED indicates that the following parameters are being displayed and can be varied: a) wire speed b) welding current c) thickness of the material to be welded d) arc height correction e) arc dynamic f) retrieving a saved job
	► During welding: The display shows the actual Amps. ► With LED HOLD access: The display shows the last measured current value.
	Switching on signals the display of the last voltage and current value measured during welding on displays 3 and 5. The LED switches off when a new welding procedure is started, or when any of the welding settings is modified.

ENGLISH

ELEMENT	FUNCTION
<p>5</p> 	<p>► During welding: The display shows the actual Volts.</p> <p>► With LED HOLD access: The display shows the last measured voltage value.</p>
<p>6</p> 	<p>Menu Key allows access to the menu through which the main characteristics of the weld are set.</p>
<p>7</p> 	<p>Program Key: Active only in MIG/MAG and MMA welding mode. When pressed it allows access to the menu from which you can select the material to be welded and/or the type of electrode used.</p>
<p>8</p> 	<p>Process Key: When pressed it allows access to the menu from which you can select the welding process to be used.</p> <p>Selectable processes:</p> <ul style="list-style-type: none"> • MIG/MAG SHORT/SPRAY • TIG • MMA
<p>9</p> 	<p>GAS Key: Active only in MIG/MAG and TIG welding mode. Pressing the key activates the gas solenoid valve to calibrate the flow pressure with the regulator mounted in the gas cylinder or centralised system.</p>
<p>10</p> 	<p>JOB Key: Personalised welding settings, or JOBS, can be saved in memory locations and subsequently uploaded.</p> <p>When pressed, it allows access to the menu for managing JOBS.</p>
<p>11</p> 	<p>TORCH TRIGGER MODE Key: Active only in MIG/MAG and TIG welding mode.</p> <p>When pressed, it allows access to the menu through which the torch trigger mode is selected.</p>
<p>12</p> 	<p>WIRE FEED Key: Active only in MIG/MAG welding mode. When pressed, it controls the wire feed.</p>
<p>13</p> 	<p>LCD: The display shows the menus for setting up the welding machine and its functions.</p>
<p>14</p> 	<p>ENCODER WITH BUILT-IN KEY</p> <p>In the menu screens: The list of parameters/settings is scrolled through the encoder. Pressing the encoder (ENCODER KEY) selects the highlighted setting.</p> <p>During welding: the encoder changes the value of the active parameter.</p>
<p>15</p> 	<p>Fast Job Keys: These keys are assigned JOBS from the quick save and recall.</p> <p>(Within the menu the assigned function is specified by the writing that appears above the key in the display).</p>

Display




ELEMENT	FUNCTION
1	WELDING PROCESS of the selected synergistic program currently in use.
2	TORCH TRIGGER MODE selected.
3	MATERIAL of the selected synergistic program.
4	DIAMETER OF THE WIRE of the selected synergistic program.
5	GAS of the selected synergistic program.
6	STATUS BAR.
7	The name of the JOB currently in use.
8	Boxes dedicated to the FAST JOBS . (FAST JOBS are JOBS that can be saved, recalled and overwritten quickly).
9	DOUBLE PULSE : the symbol is displayed with the function is active.
10	BILEVEL : the symbol is displayed when the function is active.
11	SPOT-PAUSE : the symbol is displayed when the function is active.
12	COOLING UNIT DISABLED : the symbol is displayed when the cooling unit is not provided or is disconnected.
13	LOCK : the symbol is displayed when the function is active.


ENGLISH

4 PRELIMINARY SETTINGS

4.1 LANGUAGE SETTING




1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
Select the following path: System>
3. Press the encoder key to confirm.





4. Select the following path: Languages>
5. Press the encoder key to confirm.
6. Turn the encoder to select the desired language.
o (Italiano, English, Français, Deutsch)
7. Press the encoder key to confirm.

Pressing the [Menu] key returns you to the previous screen.

4.2 FIRMWARE UPDATE



1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
Select the following path: System>
3. Press the encoder key to confirm.



4. Select the desired setting by turning the encoder.
Select the following path: FW Update
5. Press the encoder key to confirm.
6. Insert the USB pen drive with the loaded firmware into the appropriate port.



If a USB pen drive is not inserted in the appropriate port, the message "A USB pen drive with FAT32 partition must be inserted" appears on the display.
Follow the instructions on the display to start the update.
Wait for the update procedure to finish.

ENGLISH


If problems are found in the update, the display shows a notice.

NOTICE	MEANING
File not found	File not present in the USB pen drive.
A USB pen drive with a FAT32 partition must be inserted	USB pen drive not recognised (there isn't one or it is inserted incorrectly). Check the correct insertion of the USB pen drive. Use a different USB pen drive.
Could not decrypt release file	File corrupt or with changed name (never rename the provided update file).
Could not inflate release file	File corrupt or with changed name (never rename the provided update file).
Update directory and/or script not found	File corrupt or with changed name (never rename the provided update file).
Update procedure failed	Contact the customer service.
Upgrade package is not for this board	The file uploaded to the USB pen drive is not compatible with the electronic board.
Could not find readme file not found in upgrade package	Contact the customer service.
Installed version and upgrade package version do not match	You cannot downgrade the installed software.
Could not upgrade generator	Contact the customer service.
Could not upgrade boost	Contact the customer service.

4.3 SYSTEM SETTINGS



1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
Select the following path: System>
3. Press the encoder key to confirm.



4. Select the desired setting by turning the encoder.
Select the following path: Setup>
5. Press the encoder key to confirm.




ENGLISH

Wire feed setting

Using the WIRE FEED parameter, the wire threading speed that you have when you press the



[THREADING] key is set.




1. Select the desired setting by turning the encoder.
Select the following path: Wire feed>
2. Press the encoder key to confirm.
3. Press the encoder key to activate the parameter change.




4. Turn the encoder to set the desired value.
5. Press the encoder key to confirm.

Pressing the [Menu] key returns you to the previous screen.

Cooling unit setup



1. Select the desired setting by turning the encoder.
Select the following path: CU setup>
2. Press the encoder key to confirm.
3. Press the encoder key to activate the parameter change.




4. Turn the encoder to set the desired value.
 - (AUTO, ON, OFF)
 - **AUTO**: When the unit is switched on, the cooling system is switched on for 30 s. During welding procedures, the cooling system runs constantly. At the end of the welding the unit remains on for a time equal to 90 s plus a number of seconds that depends on the value of the average welding current.
 - **ON**: The cooling unit is always switched on when the current generator is also switched on. This mode is preferable for heavy duty and automatic welding procedures.
 - **OFF**: The cooling unit is always disabled; to be selected if you are using an air-cooled torch.
5. Press the encoder key to confirm.



Pressing the [Menu] key returns you to the previous screen.

ENGLISH

LOCK (Locking/Unlocking changes)



1. Select the desired setting by turning the encoder.
Select the following path: Lock>
2. Press the encoder key to confirm.
3. Press the encoder key to activate the parameter change.




4. Turn the encoder to set the desired value.
 - (LOCK PAR, LOCK JOBS).
 - **LOCK PAR.:** locks the change of all parameters except: arc length, torch trigger mode.
 - **LOCK JOBS:** locks the change of job parameters; you can scroll through the saved jobs and load them.
5. Press the [Lock] key to confirm.

Pressing the [Menu] key returns you to the previous screen.

Type a 3-digit password.

WARNING! Keep a note of the saved password as in case of loss it will be necessary to request the intervention of our Service department.




6. Turn the encoder to select the number on the keyboard.
7. Press the encoder key to confirm the selection.



8. Turn the encoder to select the [Enter] key on the keyboard.
9. Press the encoder key to confirm the password entered.
Pressing the [Menu] key returns you to the previous screen without confirming the password entered.
10. The "Unlock" item displayed on the display indicates that the change lock is active for the chosen setting.



To unlock the changes it is necessary to enter the LOCK screen.



11. Press the [Unlock] key to confirm.
Type the 3-digit password.
12. Turn the encoder to select the number on the keyboard.
13. Press the encoder key to confirm the selection.

Repeat steps 12 and 13 three times until the full password is entered.


ENGLISH



14. Turn the encoder to select the [Enter] key on the keyboard.
15. Press the encoder key to confirm the password entered.
Pressing the [Menu] key returns you to the previous screen without confirming the password entered.
16. The "Lock" item displayed indicates that the change lock has been disabled for the chosen setting.

MOTOR GENERATOR


Using the MOTOR GENERATOR parameter, the power of the motor-generator from which the equipment is powered is selected. In this way, the absorption of the welding machine is adjusted according to the power that the motor generator can deliver, thus preventing the motor generator from entering overload protection mode.



1. Select the desired setting by turning the encoder. Select the following path: Motor generator>
2. Press the encoder key to confirm.
3. Press the encoder key to activate the parameter change.



4. Turn the encoder to set the desired value.
5. Press the encoder key to confirm.




Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

ENGLISH

5 MIG/MAG WELDING

5.1 WELDING CIRCUIT CALIBRATION

Through the welding circuit calibration wizard, the resistance and inductance values of the welding circuit are detected. When the wire feeder trolley is used with the associated cable bundle, the welding circuit "R" resistance must be measured by using the calibration function. In this way it is possible to obtain a constant quality weld with cable bundles and torches of different lengths. The resistance of the welding circuit depends on the cable bundle and torch used, so it is advisable to repeat the calibration procedure when changing these components. If the power source total RESET is carried out, the calibration value will be replaced by the default value. If a partial RESET SETUP is carried out, the measured value will be stored. Calibration is not mandatory, therefore, if the user decides not to carry it out, the machine will keep the factory default value.



1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
Select the following path: Calibration>
3. Press the encoder key to confirm.



4. Press the encoder key, or the [Next] key, or the torch trigger to confirm.
5. Follow the instructions on the display (Step 1), then press the encoder key, or the [Next] key, or the torch trigger to confirm.



6. Follow the instructions on the display (Step 2), then press the encoder key, or the [Next] key, or the torch trigger to confirm.
7. Follow the instructions on the display (Step 3), then press the encoder key, or the [Next] key, or the torch trigger to confirm.

At the end of the procedure, the measured resistance and inductance values of the welding circuit will be displayed.


In this way it is possible to obtain a constant quality weld as the length of the cable bundle, ground cable and torch varies.

If the measurement is unsuccessful, the message "Calibration error" appears and the procedure can be repeated starting from Step 3.


ENGLISH

5.2 GAS FLOW ADJUSTMENT


When the unit is powered on, straight after program update, the solenoid valve opens for 1 second. This serves to fill the gas circuit.



1. Open the gas solenoid valve by pressing and releasing the  (GAS) key.



2. Adjust the pressure of gas flowing from the torch by means of the flow meter connected to the gas cylinder.



3. Close the gas solenoid valve by pressing and releasing the  (GAS) key.

i Information The solenoid valve closes automatically after 30 seconds.


5.3 WELDING PROGRAM SETTING



The [PROGRAM] key allows access to a sequence of screens through which the welding program can be chosen.





1. Press the [PROGRAM] key. Choose the combination of welding settings in the sequential screens.
 - **MATERIAL:** allows you to select the material of the filler wire for welding.
2. Turn the encoder to select the desired setting.
 - (G3/4 Si1, CrNi 316, CrNi 308, CrNi 347, AlMg5, AlSi5, Metal Cored, FCW Rutil, FCW Basic, Self shielded, CUSI3, CUA18).
3. Press the encoder key to confirm.



- **DIAMETER:** allows you to select the diameter of the filler wire for welding.
 - The available wire diameters depend on the material selected.
4. Turn the encoder to select the desired setting.
 - (e.g.: 0.8, 0.9, 1.0, 1.2.....)
5. Press the encoder key to confirm.
- **GAS:** allows you to select the type of gas for welding.
 - The gas mixtures available depend on the material selected.
6. Turn the encoder to select the desired setting.
 - (e.g.: 82% Ar - 18% CO2, 92% Ar - 8% CO2.....)
7. Press the encoder key to confirm.

ENGLISH



- **PROCESS (1 level):** allows you to select only the welding processes compatible with the settings previously made.
 - 8. Turn the encoder to select the desired setting..
 - (e.g.: MIG/MAG SHORT/SPRAY, MMA, TIG LIFT.....)
 - 9. Press the encoder key to confirm.
- **PROCESS (2 level):** allows you to select a specific type of welding process previously selected.
 - 10. Turn the encoder to select the desired setting.
 - 11. Press the encoder key to confirm.

MIG/MAG Welding processes

SYNERGISTIC MIG/MAG WELDING (STANDARD)

Welding is of the Short/Spray type.

- short arc: the drop is disconnected due to a short circuit at low amperages.
- globular: it is a transition phase between the short arc and the spray arc.
- spray arc: the deposit of material takes place without short circuits occurring at high amperages.

Synergistic means a process where the operator sets only one of the parameters chosen from Amperage, wire speed or voltage and the other parameters are adjusted automatically.

SYNERGISTIC MIG/MAG WELDING PF (POWER FOCUS)

The difference between Standard and Power Focus arc lies in its concentration and pressure that the arc exerts on the casting bath.

The concentration of the Power Focus arc allows you to focus the high temperature in the central part of the deposit.

The thermally changed area with the Power Focus arc is less widespread.

The benefits in welding are:

- greater penetration and less risk of sticking
- faster execution speed
- greater arch stability even with long stick-outs
- lower joint preparation costs
- reduction in the volumes of the weld joints to be filled

SYNERGISTIC MIG/MAG WELDING PR (POWER ROOT)

Power Root is an optimised short arc transfer with the feature of having a cold drop transfer.

Power Root allows to achieve a very high quality in root passes.

The benefits in welding are:

- first pass optimisation
- downward vertical welding quality
- excellent operation
- cold transfer of the drop
- perfect union of thin sheets
- ideal for welding joints with high gaps.

MANUAL MIG/MAG WELDING

Welding is of the Short/Spray type.

- short arc: the drop is disconnected due to a short circuit at low amperages.
- globular: it is a transition phase between the short arc and the spray arc.
- spray arc: the deposit of material takes place without short circuits occurring at high amperages.

The adjustment of the main welding parameters, wire speed, voltage and inductance, is entirely left to the operator. The optimal work point must be identified for the required welding type.

ENGLISH

MIG/MAG welding functions

DOUBLE PULSE SYNERGISTIC MIG/MAG WELDING

It is a function that can be activated in the synergistic MIG/MAG welding process (standard, power focus, power root).

This function allows the control of two wire feed speeds that alternate cyclically according to the parameters of the double speed set by the operator.

JOB-SELECTION FUNCTION

The JOB-SELECTION is a function that allows you to call and change JOBS directly from the torch trigger.

Changing from one JOB to another is also possible during welding.

This allows you to weld under different conditions (such as switching from one welding position to another) without interrupting the welding and without having to go to the user interface to change JOBS or parameters.

It is possible (by changing JOBS) to switch from one process to another as long as the saved JOB processes belong to the same process category.

Categories:

- MIG/MAG (manual, synergistic, power focus, power root and double speed)
- MMA
- TIG

B-LEVEL FUNCTION

The B-LEVEL is a function that allows you to activate a second current value during welding.


The second current value is invoked (as many times as desired) via the torch trigger without having to stop the welding process.

SPOT/PAUSE FUNCTION


The SPOT/PAUSE is a function that allows you to alternate a fixed welding time with a fixed pause time. The welding and pause times are set by the operator.

This function is useful for punching work and when you want to perform several welding sections of the same length.

5.4 MIG/MAG TORCH TRIGGER MODE SETTING





1. Press the [TORCH TRIGGER MODE] key.
2. Select the desired setting by turning the encoder.
 - (2-STROKES, 4-STROKES, 2-STROKES 3 LEVELS, 4-STROKES 3 LEVELS)
3. Press the encoder key if you only want to set the torch trigger mode, otherwise continue with the action in step (4).



4. Press the [Menu] key.
5. Select the desired setting by turning the encoder.
Select the following path: Process>
- Depending on the mode of the selected torch trigger, different process parameters are available to be set.
6. Press the encoder key to confirm.


ENGLISH



7. Turn the encoder to select the parameter to be modified.
8. Press the encoder key to activate parameter change.
9. Turn the encoder to set the desired value.
10. Press the encoder key once again to confirm the set value and select the parameters again.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

Process parameters with torch trigger in 2-strokes and 4-strokes mode



(1) Pre gas

- Time of gas delivery before the arc strike.

i Information if too long slows down the welding procedure. Other than in the presence of special requirements the value should generally be kept at 0.0 s or anyway very low.

- Adjustment range: minimum (0.0 s) - default (0.1 s) - maximum (20.0 s)

(2) Wire retraction


- The value is related to the amount of wire that is retracted at the end of welding.
- Adjustment range: minimum (0.0 s) - default (0.0 s) - maximum (10.0 s)

(3) Post gas

- Time of post gas delivery when the welding arc is extinguished.
- Adjustment range: minimum (0.0 s) - default (2.0 s) - maximum (20.0 s)

ENGLISH

Process parameters with torch trigger in 2-strokes and 3 levels mode



(1) Pre gas

- ▶ Time of gas delivery before the arc strike.
- ▶ Adjustment range: minimum (0.0 s) - default (0.1 s) - maximum (20.0 s)

(2) Starting current

- ▶ The parameter adjusts the 1st level wire feed rate as a percentage of the wire feed rate set for welding (2nd level).
- ▶ Adjustment range: minimum (10%) - default (130%) - maximum (200%)

(3) Starting Arc Corr. (Starting Arc Length Corr.)

- ▶ The parameter manages the correction of the starting current voltage.
- ▶ Adjustment range: minimum (-9.9) - default (0.0) - maximum (10)

(4) Start. Curr. Arc Time (Starting Arc Current Time)

- ▶ The parameter adjusts the time for which you stay at the starting current.
- ▶ Adjustment range: minimum (0.0 s) - default (0.5 s) - maximum (10.0 s)

(5) Slope1

- ▶ The parameter adjusts the time of the connecting slope between the starting current level and the welding level.
- ▶ Adjustment range: minimum (0.1 s) - default (0.5 s) - maximum (10.0 s)

(6) Slope2

- ▶ The parameter adjusts the time of the connecting slope between the welding level and the final current level.
- ▶ Adjustment range: minimum (0.0 s) - default (0.5 s) - maximum (10.0 s)

(7) Final current

- ▶ The parameter adjusts the 3rd level wire feed rate as a percentage of the wire feed rate set for welding (2nd level).
- ▶ Adjustment range: minimum (10%) - default (80%) - maximum (200%)

(8) Final Arc Corr. (Final Arc Length Corr.)

- ▶ The parameter manages the correction of the final current voltage.
- ▶ Adjustment range: minimum (-9.9) - default (0) - maximum (10.0)

(9) Final Arc Curr. Time (Final Arc Current Time)

- ▶ The parameter adjusts the time for which you stay at the final current.
- ▶ Adjustment range: minimum (0.0 s) - default (0.5 s) - maximum (10.0 s)

(10) Post gas


- ▶ Time of post gas delivery when the welding arc is extinguished.
- ▶ Adjustment range: minimum (0.0 s) - default (2.0 s) - maximum (20.0 s)

(11) Wire retraction

- ▶ The value is related to the amount of wire that is retracted at the end of welding.
- ▶ Adjustment range: minimum (0.0) - default (0.0) - maximum (10.0)

ENGLISH

Process parameters with torch trigger in 4-strokes and 3 levels mode



(1) Pre gas

- ▶ Time of gas delivery before the arc strike.
- ▶ Adjustment range: minimum (0.0 s) - default (0.1 s) - maximum (20.0 s)

(2) Starting current

- ▶ The parameter adjusts the 1st level wire speed rate as a percentage of the wire speed rate set for welding (2nd level).
- ▶ Adjustment range: minimum (10%) - default (130%) - maximum (200%)

(3) Starting Arc Corr. (Starting Arc Length Corr.)

- ▶ The parameter manages the correction of the starting current voltage.
- ▶ Adjustment range: minimum (-9.9) - default (0.0) - maximum (10)

(4) Slope1

- ▶ The parameter adjusts the time of the connecting slope between the starting current level and the welding level.
- ▶ Adjustment range: minimum (0.1 s) - default (0.5 s) - maximum (10.0 s)

(5) Slope2

- ▶ The parameter adjusts the time of the connecting slope between the welding level and the final current level.
- ▶ Adjustment range: minimum (0.0 s) - default (0.5 s) - maximum (10.0 s)

(6) Final current

- ▶ The parameter adjusts the 3rd level wire speed rate as a percentage of the wire speed rate set for welding (2nd level).
- ▶ Adjustment range: minimum (10%) - default (80%) - maximum (200%)

(7) Final Arc Corr. (Final Arc Length Corr.)

- ▶ The parameter manages the correction of the final current voltage.
- ▶ Adjustment range: minimum (-9.9) - default (0) - maximum (10.0)

(8) Post gas

- ▶ Time of post gas delivery when the welding arc is extinguished.
- ▶ Adjustment range: minimum (0.0 s) - default (2.0 s) - maximum (20.0 s)


(9) Wire retraction

- ▶ The value is related to the amount of wire that is retracted at the end of welding.
- ▶ Adjustment range: minimum (0.0) - default (0.0) - maximum (10.0).

ENGLISH




MIG/MAG 2T OPERATION


- ↓ : press the torch trigger
 ↑ : release the torch trigger
 ↓↑ : press and release the torch trigger



- Bring the torch up to the workpiece.
- Press (1T) and keep the torch trigger pressed.
 - The wire advances at the approach speed until it makes contact with the material. If the arc does not strike after 10 cm wire protrusion, wire feeding is locked and the welding unit outputs are de-energized.
 - The arc strikes and the wire feeder accelerates to the set feed rate value.
- Release (2T) the button to finish welding.
 - Gas flow continues for the time set in the post gas parameter (adjustable time).

MIG/MAG 2T SPOT OPERATION




-  : press the torch trigger
 : release the torch trigger
 : press and release the torch trigger




- Bring the torch up to the workpiece.
- Press (1T) and keep the torch trigger pressed.
 - The wire advances at the approach speed until it makes contact with the material. If the arc does not strike after 10 cm wire protrusion, wire feeding is locked and the welding unit outputs are de-energized.
 - The arc strikes and the wire feeder accelerates to the set feed rate value.
 - The welding procedure continues, at the preset current, for the time set with the spot time parameter.
 - After the SPOT time has elapsed, the welding ends automatically.
 - Gas flow continues for the time set in the post gas parameter (adjustable time).

ENGLISH




MIG/MAG 4T OPERATION


-  : press the torch trigger
 : release the torch trigger
 : press and release the torch trigger



- Bring the torch up to the workpiece.
- Press (1T) and release (2T) the torch trigger.
 - The wire advances at the approach speed until it makes contact with the material. If the arc does not strike after 10 cm wire protrusion, wire feeding is locked and the welding unit outputs are de-energized.
 - The arc strikes and the wire feeder accelerates to the set feed rate value.
- Press (3T) the trigger to start the weld completion procedure.
 - Gas flow continues until the torch trigger is released.
- Release (4T) the torch trigger to start the post gas procedure (adjustable time).

MIG/MAG 4T B-LEVEL OPERATION

-  : press the torch trigger
 : release the torch trigger
 : press and release the torch trigger




- Bring the torch up to the workpiece.
- Press (1T) and release (2T) the torch trigger.
 - The wire advances at the approach speed until it makes contact with the material. If the arc does not strike after 10 cm wire protrusion, wire feeding is locked and the welding unit outputs are de-energized.
 - The arc strikes and the wire feeder accelerates to the set feed rate value.
 - During normal speed welding, press and immediately release the torch trigger to switch to the second welding current.
 - The trigger must not be pressed for more than 0.3 seconds; otherwise, the weld completion stage will start.
 - When the trigger is pressed and released immediately, the system returns to the welding current.
- Press (3T) trigger and keep it pressed to start the weld completion procedure.
 - Gas flow continues until the torch trigger is released.
- Release (4T) the torch trigger to start the post gas procedure (adjustable time).

ENGLISH

MIG/MAG 2T - 3 LEVELS OPERATION


- ↓ : press the torch trigger
 ↑ : release the torch trigger
 ↓↑ : press and release the torch trigger



- Bring the torch up to the workpiece.
- Press (1T) torch trigger.
 - The wire advances at the approach speed until it makes contact with the material. If the arc does not strike after 10 cm wire protrusion, wire feeding is locked and the welding unit outputs are de-energized.
 - The welding arc strikes and the wire feed rate changes to the first welding level (hot start), which is set as a percentage of the normal welding feed rate.
 - This first level is used to create the weld pool: for example, when welding aluminium a value of 130% is recommended.
 - The hot start level continues for the start time, which is settable in seconds; then switch to normal welding speed is performed in accordance with the start slope, which can be set in seconds.
- Release (2T) the torch trigger to switch to the third welding level (crater filler), which is set as a percentage of the normal welding feed rate.
 - The switch of welding current level in terms of crater filling is performed in accordance with the crater slope, which can be set in seconds.
 - This third level is used to complete the weld and fill the final crater (crater filler) in the weld pool: for example, when welding aluminium a value of 80% is recommended.
 - The crater filler level continues for the crater time, which is settable in seconds; at the end of this time welding is interrupted and the post gas stage is performed.

MIG/MAG 2T SPOT - 3 LEVELS OPERATION

- ↓ : press the torch trigger
↑ : release the torch trigger
↑↓ : press and release the torch trigger




The welding process is the same as the 2T - 3 LEVELS process, except that the welding procedure continues, at the preset current, for the time set with the spot time parameter.
The weld is closed in the same way as with the 2T - 3 LEVELS process.

ENGLISH

MIG/MAG 4T - 3 LEVELS OPERATION


- ↓ : press the torch trigger
 ↑ : release the torch trigger
 ↓↑ : press and release the torch trigger



- Bring the torch up to the workpiece.
- Press (1T) torch trigger.
 - The wire advances at the approach speed until it makes contact with the material. If the arc does not strike after 10 cm wire protrusion, wire feeding is locked and the welding unit outputs are de-energized.
 - The welding arc strikes and the wire feed rate changes to the first welding level (hot start), which is set as a percentage of the normal welding feed rate.
 - This first level is used to create the weld pool: for example, when welding aluminium a value of 130% is recommended.
- Release (2T) trigger to switch to normal welding speed; then switch to normal welding speed is performed in accordance with the start slope, which can be set in seconds.
- Press the torch trigger again (Level 3) to switch to the third welding level (crater filler), which is set as a percentage of the normal welding feed rate.
 - The switch of welding current level in terms of crater filling is performed in accordance with the crater slope, which can be set in seconds.
 - This third level is used to complete the weld and fill the final crater (crater filler) in the weld pool: for example, when welding aluminium a value of 80% is recommended.
- Release the torch trigger a second time (4T) to close the weld and run the post gas procedure.

MIG/MAG 4T B-LEVEL - 3 LEVELS OPERATION

- ↓ : press the torch trigger
↑ : release the torch trigger
↑↓ : press and release the torch trigger




The welding process is the same as the 4T - 3 LEVELS process except that during normal speed welding pressing and immediately releasing the torch trigger switches the unit to the second welding current. The trigger must not be pressed for more than 0.3 seconds; otherwise, the weld completion stage will start. When the trigger is pressed and released immediately, the system returns to the welding current. Press (3T) trigger and keep it pressed to start the crater filler procedure. The closing of the weld takes place as the 4T - 3 LEVELS.

ENGLISH

6 PARAMETERS SETTING



The [Menu] key allows access to the menu through which the main characteristics of the weld are set. It also contains special functions such as welding circuit calibration and system menu.



1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
3. Press the encoder key to confirm the selection.

Menu items:

- **Process**
 - You can set the values of the parameters relating to the mode of the torch trigger set.
- **Double pulse**
 - You can set the values of the parameters relating to the DOUBLE PULSE welding process.
- **Welding Setup**
 - The different operating modes of the torch trigger can be activated and the parameters of the torch trigger can be set.
- **Calibration**
 - The calibration wizard can be performed through which the generator detects the resistance and inductance values of the welding circuit and self-calibrates some useful parameters. In this way it is possible to obtain a constant quality weld with cable bundles and torches of different lengths
- **System (submenu items)**
 - Languages: You set the language in which messages are displayed
 - FW Update: You will update the equipment software via USB.
 - Alarms List: All alarms reported by the equipment can be viewed through the display.
 - Info: Information regarding the use of the equipment is displayed
 - Reset: You can delete parameters, save jobs or return to factory settings.
 - Setup: The wire feed speed is set when the [WIRE FEED] key is pressed
 - Service: Reserved for personnel assigned to the technical assistance of the device.
- **Import/Export**
 - Some equipment configurations (Jobs, parameters, display setup, language) can be exported or imported via USB pen drive.

6.1 PROCESS PARAMETERS SETTING





1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: Process>
3. Press the encoder key to confirm the selection.



Depending on the mode of the selected torch trigger, process parameters are available to be set.

i Information For the list of process parameters, please refer to:

- ["Process parameters with torch trigger in 2-strokes and 4-strokes mode" on page 37.](#)
- ["Process parameters with torch trigger in 2-strokes and 3 levels mode" on page 38.](#)
- ["Process parameters with torch trigger in 4-strokes and 3 levels mode" on page 40.](#)




4. Turn the encoder to select the parameter to be modified.
5. Press the encoder key to activate parameter change.
6. Turn the encoder to set the desired value.
7. Press the encoder key once again to confirm the set value and select the parameters again.



Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

ENGLISH

6.2 SETTING DOUBLE PULSE PARAMETERS




1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: Double pulse>
3. Press the encoder key to confirm the selection.



4. Turn the encoder to select the parameter to be modified.
5. Press the encoder key to activate parameter change.
6. Turn the encoder to set the desired value.
7. Press the encoder key once again to confirm the set value and select the parameters again.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

Double pulse parameters



ACTIVATE D.P. (Activate double pulse)

- ▶ The parameter activates/disables the double pulse.
- ▶ Adjustment range: ON - OFF

(1) Welding C. (Welding current)

- ▶ The parameter adjusts the average amperes of the welding arc.
- ▶ Adjustment range: minimum (30 A) - default (30 A) - maximum (200 A)

(2) Arc Corr. (Arc Correction)

- ▶ The parameter manages the correction of the high value voltage in the MIG/MAG double pulse process.
- ▶ Adjustment range: minimum (-9.9) - default (0.0) - maximum (10)

(3) Pulse Freq. (Double speed freq.)

- ▶ This parameter adjusts the frequency of alternation of the two wire feed rates set with the **“DOUBLE SPEED AMPL.”** parameter.
- ▶ Regulation range: minimum (0.0 Hz) - default (2.0 Hz) - maximum (5.0 Hz)

(4) Double Sp. Ampl. (Double speed ampl.)

- ▶ The parameter generates the two wire speeds (high and low) used in the double pulse, which alternate with the frequency defined by the **DOUBLE SPEED FREQUENCY** parameter.
- ▶ Adjustment range: minimum (0%) - default (50%) - maximum (100%)

(5) Double sp. duty (Double Speed Duty)

- ▶ The parameter adjusts the high feed rate time.
- ▶ Adjustment range: minimum (10%) - default (50%) - maximum (90%)

(6) Arc Corr. Low (Double Speed Arc Low)

- ▶ The parameter manages the correction of the low value voltage in the MIG/MAG double pulse process.
- ▶ Adjustment range: minimum (-9.9) - default (0.0) - maximum (10)

ENGLISH

6.3 JOB SELECTION SETTING

When the JOB SEL function is active, the torch trigger operates in 4-strokes or 4-strokes 3 levels with Bilevel functions disabled. Therefore, if the Jobs have been saved in different ways, they are automatically returned in these conditions.

It is possible to scroll through the JOBS in a sequence both when you are welding and when you are not welding, by pressing and releasing the torch trigger quickly.

Swiping JOBS with UP/DOWN torch


When an UP/DOWN torch is installed, JOBS can be selected in a JOB sequence using the buttons on the welding torch. To create the JOB sequence, leave a free memory location before and after the JOB group for which you want to create the sequence.

Sequence 1			JOB not saved	Sequence 2			JOB not saved	Sequence 3		
J.01	J.02	J.03		J.05	J.06	J.07		J.09	J.10	J.11


Select and load one of the JOBS belonging to the desired sequence (for example J.06).

Using the UP/DOWN keys on the torch you can now scroll through the JOBS in sequence 2 (J.05, J.06, J.07).

With the second UP/DOWN of the torch, the arc length is adjusted.



1. Press the [Menu] key.
2. Turn the encoder to select the desired item.
Select the following path: Welding setup>
3. Press the encoder key to confirm the selection.




4. Turn the encoder to select the desired item.
Select the following path: Torch trigger>
5. Press the encoder key to confirm the selection.
6. Press the encoder key to activate the function selection.
7. Turn the encoder to select the Job-Sel function.
 - (Off, Job-Sel, B-Level).
8. Press the encoder key to confirm the selection.


Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

ENGLISH


6.4 B-LEVEL SETTING




1. Press the [Menu] key.
2. Turn the encoder to select the desired item.
Select the following path: Welding setup>
3. Press the encoder key to confirm the selection.



4. Turn the encoder to select the desired item.
Select the following path: Torch trigger>
5. Press the encoder key to confirm the selection.
6. Press the encoder key to activate the function selection.
7. Turn the encoder to select the B-Level function.
○ (Off, Job-Sel, B-Level).
8. Press the encoder key to confirm the selection and activate the parameter change.





9. Turn the encoder to set the desired value.
10. Press the encoder key to confirm the setting.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

B-LEVEL CURRENT


- The parameter enables a special torch trigger function.
 - Pressing and releasing the torch trigger rapidly in welding mode (in 2 strokes) serves to switch from the main welding current to a secondary current.
 - Pressing and releasing the torch trigger again switches from the secondary current to the main current. This switching can be performed repeatedly at the discretion of the operator.
 - To close the welding cycle (in 3 strokes) operate the torch trigger with a prolonged press. When the trigger is released the welding cycle will close (4 strokes).
- Adjustment range: minimum (0%) - default (0%) - maximum (100%).

ENGLISH


6.5 SPOT/PAUSE FUNCTION SETTING





1. Press the [Menu] key.
2. Turn the encoder to select the desired item.
Select the following path: Welding setup>
3. Press the encoder key to confirm the selection.



4. Turn the encoder to select the desired item.
Select the following path: Spot/Pause>
5. Press the encoder key to confirm the selection.
6. Press the encoder key to activate the function selection.
7. Turn the encoder to select the desired item. Select the following path: ON.
 - (OFF, ON)
8. Press the encoder key to confirm the selection.





9. Turn the encoder to select the desired item.
 - (Spot Time, Pause Time)
10. Press the encoder key to confirm the selection.
11. Turn the encoder to set the desired value.
12. Press the encoder key to confirm the setting.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

SPOT TIME

- When the torch trigger is pressed the welding arc persists for the time set in the parameter. Press the torch trigger again to resume the welding process. The welding process cannot be interrupted once it has been started. When the torch trigger is pressed, if the arc does not strike within 10 seconds, the process is deactivated. The welding parameters can be modified during the welding process.
- Adjustment range: minimum (0.0 s) - default (0.0 s) - maximum (25.0 s)


PAUSE TIME

- The parameter sets the pause time after the spot pulse.
- Adjustment range: minimum (0.0 s) - default (0.0 s) - maximum (25.0 s)

ENGLISH

7 MMA WELDING

7.1 MMA PROCESS SETUP





1. Press the [PROCESS] key to access the PROCESS menu.
2. Turn the encoder to select the desired item.
Select the following path: MMA
3. Press the encoder key to confirm the selection.





4. Press the [PROGRAM] key
5. Turn the encoder to select the desired item.
○ (Basic, Rulitic, Aluminium, CrNi).
6. Press the encoder key to confirm the selection.

7.2 PROCESS PARAMETERS SETTING

The  [Menu] button allows access to the menu through which the main characteristics of the weld are set.



1. Press the [Menu] key to access the menu.
2. Turn the encoder to select the desired item.
Select the following path: Process
3. Press the encoder key to confirm the selection.




4. Turn the encoder to select the desired item.
○ (HOT START, ARC FORCE, VRD)
5. Press the encoder key to confirm the selection.
6. Turn the encoder to set the desired value.
7. Press the encoder key to confirm the setting.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

ENGLISH

MMA PARAMETERS (PARAMETERS MENU)



(1) HOT START

- ▶ This parameter aids electrode melting at the time of arc striking. It is set as a percentage referring to the WELDING CURRENT value. The value is limited to 250A max.
- ▶ Adjustment range: minimum (0%) - default (50%) - maximum (100%)

(2) ARC FORCE


- ▶ This parameter helps to avoid electrode sticking during welding. It is set as a percentage referring to the WELDING CURRENT value.
- ▶ Adjustment range: minimum (0%) - default (40%) - maximum (200%)

(3) VRD


- ▶ This parameter activates the VRD (reduced output voltage) function. The no-load voltage value (when not welding) between the welding sockets is switched from U_0 to U_r (see technical data).
- ▶ Possible settings: (ON) - (OFF).

8 TIG LIFT WELDING

8.1 TIG LIFT PROCESS SETTING





1. Press the [PROCESS] key to access the PROCESS menu.
2. Turn the encoder to select the desired item.
Select the following path: TIG LIFT.
3. Press the encoder key to confirm the selection.




4. Turn the encoder to set the welding current.

ENGLISH


8.2 TIG TORCH TRIGGER MODE SETTING



1. Press the [TORCH TRIGGER MODE KEY].
2. Turn the encoder to select the desired item.
 - (2-STROKE, 4-STROKE)
3. Press the encoder key to confirm the selection if you only want to set the torch trigger mode. If you also want to set the process parameters, continue with the action described in point (4).



4. Press the [Menu] key.
5. Turn the encoder to select the desired item.
Select the following path: Process.
6. Press the encoder key to confirm the selection.




7. Turn the encoder to select the parameter to be modified.
 - (Slope current, Final current, Post Gas)
8. Press the encoder key to confirm the selection and activate the parameter change.
9. Turn the encoder to set the desired value.
10. Press the encoder key to confirm the setting.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

ENGLISH

Process parameters with torch trigger in 2-strokes and 4-strokes mode



(1) Slope Current

- ▶ The parameter sets the time in which the current is brought from the welding current value to the final current value via a slope. Prevents the formation of craters in the process of turning off the arc.
- ▶ Adjustment range: minimum (0.0 s) - default (1.0 s) - maximum (20.0 s)

(2) Final Current


- ▶ The parameter sets the final current value. During electrode welding the parameter makes it possible to obtain a uniform deposit of filler material from the start to the end of the welding process, closing the deposition crater with a current such as to deposit a final droplet of filler material.
- ▶ Adjustment range: minimum (0 A) - default (50 A) - maximum (500 A)

(3) Post Gas

- ▶ Time of post gas delivery when the welding arc is extinguished.
- ▶ Adjustment range: minimum (0.0 s) - default (2.0 s) - maximum (20.0 s)

TIG LIFT 2T OPERATION

- ↓ : press the torch trigger
 ↑ : release the torch trigger




- Touch the workpiece with the torch electrode.
- Press (1T) and keep the torch trigger pressed.
- Slowly raise the torch to trigger the arc.
- The welding current reaches the set value.
- Release (2T) trigger to start the weld completion procedure.
- The current reaches the final current value in a time equal to the descent slope.
- The arc is extinguished.
- The gas flow continues for a time equal to the post gas.

ENGLISH

TIG LIFT 4T OPERATION

- ↓ : press the torch trigger
 ↑ : release the torch trigger
 ⇅ : press and release the torch trigger



- Touch the workpiece with the torch electrode.
- Press (1T) and release (2T) the torch trigger.
- Slowly raise the torch to trigger the arc.
- The welding current reaches the set value.
- Press (3T) trigger and keep it pressed to start the weld completion procedure.
- The current reaches the final current value in a time equal to the descent slope.
- The electric arc remains on and a current equal to the final current is delivered.
- In these conditions it is possible to close the weld pool (crater filler current).
- Release (4T) the button to stop the arc.
- The gas flow continues for a time equal to the post gas.


9 JOBS MANAGEMENT

Personalised welding settings, or JOBS, can be saved in memory locations and subsequently uploaded. The JOB is the saving of the image of all the parameters set in the device.

By parameters we mean the values of wire speed, welding arc length, inductance/dynamics, slopes, torch trigger mode, process, program used, special functions, guard limits, etc ...

The settings of the SETUP menu are not saved.



There are 100 JOBS available.



Press the [JOB] key to access the JOB MENU from which you can save, load or delete JOBS.

9.1 SAVING A JOB

Access the JOB MENU.





1. Press the [Save] key.
The screen from which to select the JOB save location appears.
2. Turn the encoder to select the first free position on which to save the JOB.
3. Press the encoder key to confirm the save position of the JOB.

The keyboard for typing the name appears.

ENGLISH

Keyboard functions

- (1) Letters
- (2) Uppercase letters
- (3) Special numbers/characters
- (4) Spacebar
- (5) Delete text
- (6) Save and exit




4. Turn the encoder to select the letter on the keyboard.
5. Press the encoder key to confirm the selection.
(repeat steps 4 and 5 until the JOB name is complete)
6. Turn the encoder to select the [Save and Exit] key on the keyboard, then press the encoder key to store the JOB and return to the "JOB MENU" screen.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.


9.2 OVERWRITE A JOB

Access the JOB MENU.



1. Press the [Save] key.
2. Turn the encoder to select the JOB to be replaced.
3. Press the encoder key to confirm the Job number.

The keyboard for typing the name appears.




4. Turn the encoder to select the letter on the keyboard.
5. Press the encoder key to confirm the selected letter.
(repeat steps 4 and 5 until the JOB name is complete)
6. Turn the encoder to select the [Save and Exit] key on the keyboard.
7. Press the encoder key to overwrite the JOB and return to the "JOB MENU" screen.

Press the [Menu] key twice to return to the main screen or once to return to the previous screen.

ENGLISH

9.3 LOAD A JOB



Enter the JOB screen, with the list of stored JOBS.



1. Turn the encoder to select the JOB to load.
2. Press the encoder key or the [Load] key.
3. The name of the loaded JOB appears on the main screen.

9.4 DELETING A JOB

Enter the JOB screen, with the list of stored JOBS.




1. Turn the encoder to select the JOB to be deleted.
2. Press the [Delete] key.
3. Turn the encoder to select "YES".
4. Press the encoder key to confirm the deletion.
5. Selecting "NO" and pressing the encoder key does not delete the JOB and returns to the "JOB MENU" screen.

9.5 EXPORT JOBS



1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
Select the following path: Import/Export>
3. Press the encoder key to confirm.



4. Insert a USB pen drive into the USB port.
5. Select the desired setting by turning the encoder.
Select the following path: Export Jobs>
6. Press the encoder key to confirm.
7. Turn the encoder to select "YES".
8. Press the encoder key to export the files to the USB pen drive.
If the export is successful, the message "Export OK" appears.



i Information If at point "8" the system does not detect the presence of the USB pen drive on the port, the message "A USB pen drive with FAT32 partition must be inserted" appears on the display.

i Information If "NO" is selected at point "7", at the command of point "8" the Jobs are not exported and you return to the previous page.

ENGLISH

9.6 IMPORT JOBS



1. Press the [Menu] key.
2. Select the desired setting by turning the encoder.
Select the following path: Import/Export>
3. Press the encoder key to confirm.



4. Insert a USB pen drive into the USB port.
5. Select the desired setting by turning the encoder.
Select the following path: Import Jobs>
6. Press the encoder key to confirm.
7. Turn the encoder to select "YES".
8. Press the encoder key to import the USB pen drive files.
If the export is successful, the message "Import OK" appears.




i Information If at point "8" the system does not detect the presence of the USB pen drive on the port, the message "A USB pen drive with FAT32 partition must be inserted" appears on the display.


i Information If the files on the USB pen drive occupy the same position (number before the name) as those already in the generator, the latter will be overwritten by those on the pen drive.


9.7 FAST JOB

The "FastJob" function saves the image of the parameter setting currently in use quickly on a maximum of 3 memory locations of the Jobs (the first 3).

Saved FastJobs will be displayed in the relevant FastJob boxes



1. Press the key  and hold for 3 seconds.
2. In the box located above the key pressed, the storage signal that has occurred appears: ✓
3. On release, the saved Job number appears in the relevant box.

If we press the button  for 3 seconds, the new FastJob is automatically overwritten on the previously saved one.
(the signal will always appear: ✓)

To exit Job mode, simply rotate one of the encoders.

ENGLISH

10 RESET

Reset Mode

► Reset parameters

The "Reset parameters" procedure resets the parameter values to factory settings, except for the following settings:

- Language.
- Saved JOBs.

► Reset parameters and Job

The "Reset parameters and Job" procedure implements the complete reset of values, parameters and memories to factory settings except for the following settings:

- Language.



► Factory reset

The "Factory Reset" procedure implements the complete reset of values, parameters and memories and the settings of the Setup menu to those of the factory.


10.1 RESET PARAMETERS



1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: System>
3. Press the encoder key to confirm.



4. Turn the encoder to select the desired setting.
Select the following path: Reset>
5. Press the encoder key to confirm.
6. Turn the encoder to select the desired setting.
Select the following path: Reset parameters>
7. Press the encoder key to confirm.





8. Turn the encoder to select "YES".
9. Press the encoder key to confirm the reset of the parameters.


i Information Selecting "NO" and pressing the encoder key returns to the previous page without resetting the parameters.

ENGLISH


10.2 RESET PARAMETERS AND JOBS



1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: System>
3. Press the encoder key to confirm.



4. Turn the encoder to select the desired setting.
Select the following path: Reset>
5. Press the encoder key to confirm.
6. Turn the encoder to select the desired setting.
Select the following path: Reset parameters and jobs>
7. Press the encoder key to confirm.




8. Turn the encoder to select "YES".
9. Press the encoder key to confirm the reset of parameters and jobs.



i Information Selecting "NO" and pressing the encoder key returns you to the previous page without resetting the parameters and jobs.

ENGLISH


10.3 FACTORY RESET



1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: System>
3. Press the encoder key to confirm.



4. Turn the encoder to select the desired setting.
Select the following path: Reset>
5. Press the encoder key to confirm.
6. Turn the encoder to select the desired setting.
Select the following path: Factory reset >
7. Press the encoder key to confirm.






8. Turn the encoder to select "YES".
9. Press the encoder key to confirm the system reset to factory settings.

i Information Selecting "NO" and pressing the encoder key returns you to the previous page without performing any type of reset.



ENGLISH

11 ALARM MANAGEMENT

i Information The function is enabled when you are not welding.



1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: System>
3. Press the encoder key to confirm.



4. Turn the encoder to select the desired setting.
Select the following path: Alarms List>
5. Press the encoder key to confirm.
The list of stored alarms is displayed.
6. Press the "Reset" key if you want to delete the list.

i Information When an alarm condition occurs all functions are disabled, except for:

- cooling fan
- cooling unit (if active).

Alarms list

E02: NTC DISCONNECTED ALARM

- ▶ Indicates the information interruption between the NTC and the control system.
- ▶ Solution:
 - Qualified technical staff must be called out to carry out the repairs/maintenance operations.

E04: VOUT DISCONNECTED ALARM

- ▶ Indicates that there is a short circuit between the (+) and (-) welding sockets.
- ▶ Solution:
 - Check that the welding torch is not resting on the piece to be welded connected to the ground.
 - Check that when the generator is switched on there is no short circuit between the sockets (the voltage must be greater than/equal to U_r).
 - If the problem persists, qualified technical personnel are required for repair/maintenance.

E05: WELD TORCH TRIGGER PRESSED ALARM

- ▶ Indicates that when the generator was switched on, a short circuit was detected on the input of the torch trigger. When the problem ceases, the power generator will reset automatically.
- ▶ Solution:
 - Make sure that the torch trigger is not pressed, jammed, or short circuiting.
 - Check that the torch and torch connector are intact.

E22: BOOST VOLTAGE HOLE ALARM

- ▶ Indicates that there has been a rapid lack of voltage in the mains power supply
- ▶ Solution:
 - Check the stability of the electric power distribution if the problem occurs frequently.
 - When the problem is solved, the welding power source will reset automatically.

E23: BOOST CURRENT LIMIT ALARM

- ▶ Mains Boost overcurrent
- ▶ Solution:
 - Qualified technical staff must be called out to carry out the repairs/maintenance operations.

E25: BOOST CURRENT NOT CALABRATED ALARM

- ▶ Phase absorption unbalance
- ▶ Solution:
 - Qualified technical staff must be called out to carry out the repairs/maintenance operations.

E26: GROUND CURRENT ALARM

- ▶ Current is re-circulated on the ground circuit
- ▶ Solution:
 - Qualified technical staff must be called out to carry out the repairs/maintenance operations.

ENGLISH

E27: POWER SUPPLY UNDERVOLTAGE ALARM

- ▶ Low supply voltage
- ▶ Solution:
 - Check that the mains power supply does not fall below the minimum allowed values.

E28: POWER SUPPLY OVERVOLTAGE ALARM

- ▶ High supply voltage
- ▶ Solution:
 - Check that the mains power supply does not exceed the maximum allowed values.

E30: PRIMARY OVERCURRENT ALARM

- ▶ Exceeding the current threshold at the primary
- ▶ Solution:
 - The welding currents are at the limit of the maximum threshold: lower the welding parameters.
 - If the problem persists, qualified technical personnel are required for repair/maintenance.

E31: INVERTER THERMAL ALARM

- ▶ It indicates that the welding power source thermal cut-out switch has tripped.
- ▶ Solution:
 - Leave the equipment running so that the overheated components cool as rapidly as possible. When the problem is solved, the welding power source will reset automatically.
 - Check the correct operation of the fans.
 - Make sure that the power required by the welding process is lower than the maximum rated power output.
 - Check that the operating conditions are in compliance with the welding power source data plate specifications.
 - Check for the presence of adequate air circulation around the welding power source.

E32: SECONDARY THERMAL ALARM

- ▶ It indicates that the welding power source thermal cut-out switch has tripped.
- ▶ Solution:
 - Leave the equipment running so that the overheated components cool as rapidly as possible. When the problem is solved, the welding power source will reset automatically.
 - Check the correct operation of the fans.
 - Make sure that the power required by the welding process is lower than the maximum rated power output.
 - Check that the operating conditions are in compliance with the welding power source data plate specifications.
 - Check for the presence of adequate air circulation around the welding power source.

E50: COOLING UNIT ALARM

- ▶ Indicates insufficient pressure in the torch liquid cooling circuit.
- ▶ Solution:
 - Check that the connection to the cooling system is correct.
 - Check that the O/I switch is in the "I" position and that it lights up when the pump is running.
 - Check that the cooling liquid is present in the cooling unit.
 - Check that the pump flows the liquid (presence of external by-pass)
 - Check that the cooling circuit is liquid tight, notably the torch hoses, the fuse and the internal connections of the cooling unit.
 - Check the correct operation of the fans.
 - If the problem persists, qualified technical personnel are required for repair/maintenance.

E61: WIRE FEEDER - ENCODER ALARM


- ▶ Current absorbed by the motor high.
- ▶ Solution:
 - Check if the motor is mechanically blocked by some object.
 - If the problem persists, qualified technical personnel are required for repair/maintenance.

ENGLISH


12 INFO SYSTEM



1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: System>
3. Press the encoder key to confirm.



4. Turn the encoder to select the desired setting.
Select the following path: Info>
5. Press the encoder key to confirm.
A screen is displayed on which the following information is displayed:
 - Generator model;
 - Generator serial number;
 - Number of hours of machine on;
 - Number of weld hours;
 - Pkg



i Information After 5 seconds the system loads the list of cards with microcontroller and the respective firmware version:

- Display;
 - Boost;
 - Inverter;
 - WF.
6. Turn the encoder to scroll through the list of information.
 7. Press the encoder key to exit the "INFO" screen and return to the previous screen.

13 SERVICE



The service menu is used to activate additional functions;

The password is not provided to the end user as the activation of these functions is reserved for qualified technical personnel authorised by the manufacturer for maintenance and troubleshooting of the equipment.


Below is the procedure to be followed to access the Service menu.



1. Press the [Menu] key.
2. Turn the encoder to select the desired setting.
Select the following path: System>
3. Press the encoder key to confirm.



4. Turn the encoder to select the desired setting.
Select the following path: Service>
5. Press the encoder key to confirm.
The Service page appears in which the "Login>" item is present.
6. Press the encoder key to confirm.



ENGLISH







To access the service menu, enter the three-digit password.




i Information The password to access the Service menu is provided only to authorised technical personnel (dealers or qualified maintenance personnel authorised by the manufacturer).

7. Turn the encoder to select the number on the keyboard.
8. Press the encoder key to confirm the selection.
9. Repeat operations "7" and "8" to enter the three-digit password.
10. Turn the encoder to select the [Enter] key on the keyboard.
11. Press the encoder key to confirm the password entered and access the Service menu.

14 TECHNICAL DATA



Directives applied	Waste electrical and electronic equipment (WEEE)
	Electromagnetic compatibility (EMC)
	Low voltage (LVD)
	Restriction of the use of certain hazardous substances (RoHS)
	Eco Design of energy-related products
Construction standards	EN 60974-1; EN 60974-5; EN 60974-10 Class A
Conformity markings	 Equipment compliant with European directives in force
	 Equipment suitable in an environment with increased hazard of electric shock
	 Equipment compliant with WEEE directive
	 Equipment compliant with RoHS directive

14.1 MICROMAG 225

Supply voltage	1 x 230 Va.c. \pm 15% 50/60 Hz			
Network protection	16 A Delayed			
Zmax				
Dimensions	height: 368 mm / width: 226 mm / depth: 509 mm			
Weight	16.0 kg			
Insulation class	H			
Protection rating	IP23S			
Cooling	AF: Forced air cooling (with fan)			
Maximum gas pressure	0,5 MPa (5 bar)			
Static characteristic	MMA:  Falling characteristic			
	TIG:  Falling characteristic			
	MIG:  Static characteristic			
Welding mode		MMA	TIG	MIG
Current and voltage regulation range		10 A - 20.4V 180 A - 27.2 V	10 A - 10.4 V 220 A - 18.8 V	10 A - 14.5 V 220 A - 25.0 V
Welding current / Working voltage	30% (40°C)	---	---	220 A - 25.0 V
	40% (40°C)	180 A - 27.2 V	---	---
	55% (40°C)	---	220 A - 18.8 V	---
	60% (40°C)	155 A - 26.2 V	210 A - 18.4 V	175 A - 22.8 V
	100% (40°C)	125 A - 25.0 V	175 A - 17.0 V	145 A - 21.2 V
Maximum power absorbed	30% (40°C)	---	---	6.5 KVA - 6.4 KW
	40% (40°C)	5.7 KVA - 5.6 KW	---	---
	55% (40°C)	---	5.0 KVA - 4.9 KW	---
	60% (40°C)	4.7 KVA - 4.6 KW	4.8 KVA - 4.6 KW	4.8 KVA - 4.6 KW
	100% (40°C)	3.7 KVA - 3.6 KW	3.7 KVA - 3.6 KW	3.7 KVA - 3.6 KW
Maximum current absorbed	30% (40°C)	---	---	28.4 A
	40% (40°C)	25.3 A	---	---
	55% (40°C)	---	21.6 A	---
	60% (40°C)	20.7 A	20.7 A	20.7 A
	100% (40°C)	16.0 A	16.0 A	16.0 A
Actual current absorbed	30% (40°C)	---	---	15.5 A
	40% (40°C)	16.0 A	---	---
	55% (40°C)	---	16.0 A	---
	60% (40°C)	16.0 A	16.0 A	16.0 A
	100% (40°C)	16.0 A	16.0 A	16.0 A
Open voltage (U0)	52 V			
Reduced open voltage (Ur)	5 V			

ENGLISH

Energy source efficiency	Efficiency (MIG @ 220 A / 25 V): 87.3%
	Energy consumption under no-load conditions (U1= 230 Va.c.): 26 W
Essential raw materials	According to the information provided by our suppliers, this product does not contain essential raw materials in quantities greater than 1 g per component.



15 SPARE PARTS

15.1 WIRE FEEDER ROLLS

			
CODE	DESCRIPTION	Ø WIRE	TYPE
002.0000.0140	ROLLER 0.6/0.8 D=37x12/D=19 V	0.6/0.8	  35° V-shaped groove for solid wires (steel, stainless steel)
002.0000.0141	ROLLER 0.8/1.0 D=37x12/D=19 V	0.8/1.0	
002.0000.0142	ROLLER 1.0/1.2 D=37x12/D=19 V	1.0/1.2	
002.0000.0143	ROLLER 1.2/1.6 D=37x12/D=19 V	1.2/1.6	
002.0000.0144	ROLLER 0.8/1.0 D=37x12/D=19 U	0.8/1.0	  90° V-shaped groove for aluminium wires
002.0000.0145	ROLLER 1.0/1.2 D=37x12/D=19 U	1.0/1.2	
002.0000.0146	ROLLER 1.2/1.6 D=37x12/D=19 U	1.2/1.6	
002.0000.0147	ROLLER 1.6/2.0 D=37x12/D=19 U	1.6/2.0	
002.0000.0148	ROLLER 2.4/3.2 D=37x12/D=19 U	2.4/3.2	  90° knurled VK-groove for tubular wires
002.0000.0149	ROLLER 1.0/1.2 D=37x12/D=19 VK	1.0/1.2	
002.0000.0150	ROLLER 1.2/1.6 D=37x12/D=19 VK	1.6/2.0	
002.0000.0151	ROLLER 2.4/3.2 D=37x12/D=19 VK	2.4/3.2	
002.0000.0303	SMOOTH ROLLER WITH BEARINGS		
002.0000.0152	ROLLER D=37x12/D=19 SMOOTH		
002.0000.0153	ROLLER D=37x12/D=19 KNURLED		

- The diameter of the roll groove must be compatible with the diameter of the welding wire.
- The roll must be of suitable shape in relation to the composition of the wire material.
 - The groove must be "V 90°" for soft materials (Aluminium and its alloys, CuSi3).
 - The groove must be "V 35°" for harder materials (SG2-SG3, stainless steels).
 - The groove must be "VK 90°" knurled for flux-cored wire.



ENGLISH





WELD THE WORLD

WECO srl
www.weco.it

Code 006.0001.2360
20/05/2024 V.1.0

